



ITEM NO.	PART NUMBER	QTY.
3	M8 x 20mm bolt	4
4	M8 T Type nyloc nut	4
5	8mm Form C washer	8

Extension panels are fitted using the 4 M8 x 20mm bolts, washers and nuts provided as per the diagram. Ensure that the straight side is at the front of the racking and the sloping side "follows" the contours of the van.(end panel extensions are left-handed or right-handed)These instructions apply to ladder frame extensions also.

TITLE:

End Panel/ladder Extension fitting guide

Bolt Kit blk005

Copyright