



Offer the floor angle in between the end panels/ladder frames with the rear face towards the side of the van. Insert the bolts as per the diagram, tighten loosely. Drive the self tappers (5) through the floor and then fully tighten the bolts.

ITEM NO.	PART NUMBER	QTY.
2	M6x12mm bolt	2
3	M8 x 25mm washer	4
4	6mm nyloc	2
5	M4x12mm panhead self tapper	5

TITLE:

**Floor angle fixing guide**

**Bolt kit : Blk001**