



ITEM NO.	PART NUMBER	QTY.
3	100mm box section	1
4	M8x45mm bolt	2
5	M8 T Type nyloc nut	2
6	8mm x 25mm washer	4
7	M10 nut	1

The ladder frame will need cutting around the wheel box. Measure and cut 35mm above the wheel box out of the rear leg and appropriately out of the floor section. Line up the ladder frame holes with the holes in the 100mm box section and use the 2 x M8 x 45mm bolts(4) provided to bolt it into position, Adjust the foot and tighten the locknut(7)

Note;Bottom hole must be at least 35mm up the box section to allow foot to adjust fully

TITLE:

Adjustable foot over wheelbox fixing guide

Boltkit: BIK015