



ITEM NO.	PART	QTY.
2	M8 x16mm bolt	4
3	M8 T Type nyloc nut	4
4	8mm x 25mm washer	8

Offer the strongbar upto the underside of the drawer/shelf etc to be supported, Pass the bolts(2) through the strongbar and the end panel/ladder frame holes with the nuts(4) on the inside. Ensure shelf/drawer is straight and level and that the strongbar is up tight against the underside before fully tightening.

TITLE:

Reinforcement bar Fixing Diagram

Bolt kit: blk004